

## INSTRUCTIONS FOR READING AND CLEANING 32MM STOCK AND GARDEN METERS

### Owner Responsibilities

1. Keep area clear of weeds and rubbish;
2. Monitor usage to ensure you remain within current water allocation;
3. Notify WMI of any meter or outlet malfunctions; and
4. Clean filter as required as per instructions on the next page.

### Meter Reading

BLACK Numbers

1

2

3

4

5

10 ML

1 ML

100,000 l

10,000 l

1,000 l

- Example above = 12.345ML
- When the 2nd digit from left changes from 0 to 1 = Used 1 megalitre (ML).  
One megalitre (1ML) equals one million litres (1,000,000 l).

**This Reading = 50,000 litres**

**OR**

**0.050ML**

## Filter Cleaning

1. Remove lid from Meter Box.
2. Turn off 32mm gate valve located before the filter.
3. Release the pressure in the pipe by opening a garden tap and leave the tap open.
4. Carefully unscrew the filter bowl by turning **anticlockwise**.
5. Remove filter screen and clean by turning on the 32mm gate valve. Once clean close the gate valve again.
6. Replace filter screen and carefully screw filter bowl back on by turning **clockwise**.
7. Turn 32mm gate valve back on slowly **1 Turn** and wait until water is coming out of the garden tap.
  - Turn the garden tap OFF
8. Check filter for any leaks. If leaking Repeat steps 2 – 7.
9. If all O.K. open gate valve fully and replace lid on Meter Box.

